

【UX302NC 動作確認機種一覧】

2016 年 1 月 22 日現在

- ◇ 一覧に無い機種は、動作確認を行っていない機種であり正常に動作しないというものではありません。
- ◇ 一覧の機種は全てクリーンインストール状態で確認しており、お客様の環境において正常動作を保証するものではありません。
(周辺機器の追加やインストールアプリケーション追加などの影響により正常に動作しない場合があります。)

■ PC 接続確認済機種一覧

メーカー	型番		OS	備考
Acer	ICONIA W510D		Windows8	
Acer	Aspire 5741	AS5741-H32C/SF	Windows7 Home Premium SP1(64bit)	
Acer	Aspire one D250	AOD250-Bk83	WindowsXP Home Edition SP3	
Acer	Aspire	S3-391-F54D MS2346	Windows 10 Home (64bit)	
Apple	MacBook Pro	MC700J/A	MacOSX 10.9(64bit)	
Apple	MacBook Pro	MC976J/A	MacOSX 10.8(64bit)	
Apple	MacBook Pro	MD103J/A	MacOSX 10.7.4(64bit)	
Apple	MacBook Pro	MC724J/A	MacOSX 10.6.7(64bit)	
Apple	MacBook Air	MD223J/A	MacOSX 10.9(64bit)	
Apple	MacBook Air	MD231J/A	MacOSX 10.8.2(64bit)	
Apple	MacBook Air	MD231J/A	MacOSX 10.7.4(64bit)	
Apple	MacBook Air	MC503J/A	MacOSX 10.6.5	
Apple	MacBook Pro	MC700J/A	Mac OS X 10.10.3 (64bit)	
Apple	MacBook Pro	MC724J/A	Mac OS X 10.10.3 (64bit)	
Apple	MacBook Pro	MC372J/A	Mac OS X 10.11 (64bit)	アップグレード
ASUS	Eee PC	1000H-X	WindowsXP Home Edition SP3	
ASUS	X202E-CT3217	AR5B225	Windows 10 Home (64bit)	
ASUS	X301A-RXB980D		Windows 10 Home (64bit)	
ASUS	VivoBook S550CM	S550CM-CJ3317	Windows 10 Home (64bit)	
DELL	Latitude 10		Windows8	
DELL	Latitude E6220		Windows7 Professional SP1	
DELL	Inspiron M301z		Windows7 Home Premium SP1(64bit)	
DELL	Studio 1737	PP31L	WindowsVista Home Premium SP1	
DELL	Inspiron mini 910		WindowsXP SP3	
DELL	ALIENWARE M17x	P01E	Windows7 Ultimate SP1 (64bit)	
FUJITSU	LIFEBOOK A574/H	FMVA05003	Windows8.1 Pro(64bit)	
FUJITSU	STYLISTIC QH77/J FMVQ77J		Windows8(64bit)	
FUJITSU	LIFEBOOK AH54/E	FMVA54EB	Windows7 Home Premium SP1(64bit)	
FUJITSU	STYLISTIC QH77	J FMVQ77J	Windows 10 Home (64bit)	
FUJITSU	LIFEBOOK AH54	E FMVA54EB	Windows7 Home Premium SP1 (64bit)	
FUJITSU	LIFEBOOK SH76	HN FMVS7HN5S8	Windows7 Professional SP1 (64bit)	
HP	ProBOOK 4525s	HSTNN-W80C	Windows7 Professional SP1	
HP	ENVY	dv6-7202AX	Windows 10 Home (64bit)	
HP	HP Pavilion Sleekbook 14-b002au	TPN-Q115	Windows 8.1 (64bit)	
HP	ENVY x2 11-G005tu	TPN-P104	Windows8 (32bit)	
Lenovo	ThinkPad Tablet2 3679-4DJ		Windows8 Pro	
Lenovo	ThinkPad Edge E220s	50384FJ	Windows7 Professional SP1(64bit)	
Lenovo	X201 3626-FJJ		WindowsXP Professional SP3	

Lenovo	IdeaPad Z480	2148	Windows 10 Home (64bit)	
Lenovo	ThinkPad T410	2522-AP3	Windows 10 Pro (32bit)	
Lenovo	G580	2189-DCJ	Windows 10 Home (64bit)	
Lenovo	ThinkPad10	20C1S00U00	Windows 8.1 Pro update (32bit)	
Lenovo	IdeaPad Z480	2148	Windows8 (64bit)	
Lenovo	ThinkPad Edge E220s	5038-4FJ	Windows7 Professional SP1 (64bit)	
Lenovo	ThinkPad Edge 13	0197CTO	Windows7 Home Premium SP1 (64bit)	
Lenovo	ThinkPad T410i	2516-F7J	Windows7 Professional SP1 (32bit)	
NEC	Lavie M LM750/JS		Windows8(64bit)	
NEC	LaVie LM550/FS6W	PC-LM550FS6W	Windows7 Home Premium SP1(64bit)	
NEC	Lavie M LM750	JS6W PC-LM750JS6W	Windows 10 Home (64bit)	
NEC	LaVie LM550	FS6W PC-LM550FS6W	Windows7 Home Premium SP1 (64bit)	※右奥、右手前 USB3.0 ポートで使用する場 合、事前に USB3.0 ホ ストドライバのアップ デートが必要になりま す。
NEC	LaVie LL750	FS6R PC-LL750FS6R	Windows7 Home Premium SP1 (64bit)	※左奥、左手前 USB3.0 ポートで使用する場 合、事前に USB3.0 ホ ストドライバのアップ デートが必要になりま す。
NEC	LaVie L LL750	AS6R PC-LL750AS6R	Windows7 Home Premium SP1 (32bit)	※左奥、左手前の USB3.0 ポートでは使 用できません。
Panasonic	Let'snote B11 CF-B11QWABR		Windows8.1(64bit)	
Panasonic	Let'snote AX2 CF-AX2LEABR		Windows8 Pro(64bit)	
Panasonic	Let's note CF-NX2	CF-NX2LEABR	Windows 10 Pro (64bit)	
Panasonic	Let's note CF-AX2	CF-AX2LEABR	Windows 10 Pro (64bit)	
Panasonic	Let's note CF-RZ4	CF-RZ4CDDJR	Windows 10 Home (64bit)	
Panasonic	Let's note CF-B11	CF-B11QWABR	Windows 8.1 Pro (64bit)	
Panasonic	Let's note CF-J10	CF-J10PYAHR	Windows 8.1 Pro (32bit)	
Sony	SVS15129CJB		Windows8(64bit)	
Sony	VAIO C シリーズ	VPCCB39FJ/P	Windows7 Home Premium SP1(64bit)	
Sony	VAIO VGN-FE32BW		WindowsVista Home Premium SP2	
SONY	SVS15129CJB	SVS151C1SN	Windows 10 Home (64bit)	
SONY	SVE14129CJP	SVE141L11N	Windows 10 Home (64bit)	
SONY	VAIO	SVT131A11N	Windows 10 Pro (64bit)	
SONY	SVS15129CJB	SVS151C1SN	Windows 8.1 (64bit)	
TOSHIBA	Dynabook R632/W0LGS PR6320LGNNWSW-K		Windows8.1(64bit)	
TOSHIBA	dynabook T552/47GK		Windows8(64bit)	
TOSHIBA	dynabook R731/38DK	PR73138DRJK	Windows7 Professional SP1	
TOSHIBA	dynabook TX TX/66J2	PATX66J2LP	WindowsVista Home Premium SP2	
TOSHIBA	dynabook UX/23JBL	PAUX23JNLBL	WindowsXP Home Edition SP3	
TOSHIBA	dynabook R632	W0LGS PR6320LGNNWSW	Windows 10 Home (64bit)	
TOSHIBA	dynabook T552	47GK PT55247GBHK	Windows 10 Home (64bit)	
TOSHIBA	dynabook Satellite T571	W5TE PT5715TEBGBW	Windows 10 Home (32bit)	

TOSHIBA	dynabook satellite B352	W2CGW	Windows 10 Home (64bit)	
TOSHIBA	dynabook T451	46ER PT45146ESFR	Windows7 Home Premium SP1 (32bit)	※左の USB3.0 ポート では使用できません。
TOSHIBA	dynabook R731	38DK PR73138DRJK	Windows7 Professional SP1 (64bit)	※右の USB3.0 ポート で使用する場合、事前 に USB3.0 ホストドラ イバのアップデートが 必要になります。
TOSHIBA	dynabook R632	28FS PR63228FMFS	Windows7 Home Premium SP1 (64bit)	
TOSHIBA	dynabook R632	W1RFS PR6321RFMFWSW	Windows7 Home Premium SP1 (64bit)	
TOSHIBA	dynabook R63/P	PR63PEAA637AD71 PR63PCAA637AD71 PR63PBAA637AD71	Windows7 Professional SP1 (32bit/64bit) Windows8.1 Pro Update (64bit)	※非対応 端末の挿抜により、PC がシャットダウンする 場合があります。